



1. Cut slate as required and interleave with code 3 lead soakers, dressed to provide at least 75mm upstand to form a close, weathertight abutment, fix soakers by turning down over the head of each slate.
2. Fix code 4 lead flashing over soaker. Welt top edge, secure into the brickwork joints, to a depth of at least 25mm, with lead wedges and point in mortar

**SSQ NATURAL SLATE
TYPICAL ABUTMENTS AND PARAPETS DETAIL
AT END OF ROOF SLOPES
500X250 DEL CARMEN, ULTRA GRADE (NATURAL SLATE)
DRG 007**