



FIXING IN ACCORDANCE WITH THE MANUFACTURERS
PRINTED INSTRUCTIONS, BS5534 PART 1 2014,
BS8000 PART 6 2013 AND H62/210 AND 275

CODE 4 LEAD FLASHING SECURED
INTO BRICKWORK WITH LEAD WEDGES
FIXING IN ACCORDANCE WITH THE MANUFACTURERS
PRINTED INSTRUCTIONS, BS EN 12588:2006

SLATES INTERLEAVED WITH CODE 3 LEAD
SOAKERS, MINIMUM 75mm UPSTAND

1. Turn underlay 100mm up abutments.
2. Fix short slates as the top course to maintain gauge.
3. Fix code 6 lead tack, 50mm wide, at 300 to 500mm centres and laps.
4. Fix code 4 lead apron flashing in 1.5 to 2.0m lengths, wedge at the laps and at 450mm centres and secure into the brickwork joints to a depth of at least 25mm, dressed down 150mm over the slates.

SSQ NATURAL SLATE
TYPICAL ABUTMENTS AND PARAPETS DETAIL
AT TOP OF ROOF SLOPE
500X250 DEL CARMEN, ULTRA GRADE (NATURAL SLATE)
DRG 008

