



1. Mortar 1:3 cement/sand pigmented to approved colour.
2. Fix 600mm wide underlay, overlapping the main underlay
3. Fix hip to iron (to BS 5534: Part 1: Clause 12) to hip rafter.
4. Cut slates to fit closely at junction.
5. Lay hip ridge tiles true and bed edges and joints firmly in mortar, struck off smoothly to provide a flush finish.
5. Cut first tile to align with corner of eaves.
6. Fill end of hip with mortar and slips of slate finished flush.

**SSQ NATURAL SLATE**  
**TYPICAL RIDGE TILED HIP DETAIL**  
**500X250 DEL CARMEN, ULTRA GRADE (NATURAL SLATE)**  
**DRG 004**

