



1. Fix valley boards down length of gutter.
2. Fix tilting fillets on either side of the valley board and dress underlay over these tilting fillets.
3. Dress code 5 lead strip at least 500mm wide, into the gutter and over the tilting fillets, extending at least 40mm beyond each tilting fillets.
4. Cut slates accurately, ensuring sufficient width is retained at the tail, to overhang the tilting fillet but leave a minimum of 100mm clear width of valley.

NOTE: The edges of the slating should not be tilted up over open valleys

SSQ NATURAL SLATE
TYPICAL VALLEY GUTTER LEAD DETAIL
500X250 DEL CARMEN, ULTRA GRADE (NATURAL SLATE)
DRG 005

