



FIXING IN ACCORDANCE WITH THE
MANUFACTURERS PRINTED INSTRUCTIONS,
BS5534 PART 1 2014, BS8000 PART 6 2013
AND H62/210 AND 275

SARKING FELT EXTENDED
OVER UNDERCLOAK

UNDERCLOAK BEDDED
IN MORTAR

MAX 50mm

1. Bed the undercloak in mortar so that it extends 50mm from the face of the wall.
2. Fix verge slates flush with the undercloak.
3. Fill the gap between the undercloak and the slates with mortar and strike off smoothly to provide a flush joint and cut back joint as shown.

SSQ NATURAL SLATE
TYPICAL VERGE DETAIL
500X250 DEL CARMEN, ULTRA GRADE (NATURAL SLATE)
DRG 002